

ZETTLER® Medical® 800

Nurse Control Station

Features:

- New audio monitoring feature
- Room lists can be sequentially monitored without alerting the patient
- Programming of outputs that are activated with a call
- Assignment of a room to a group is possible
- All menus can be password protected with the new password control application



Nurse Control Station

Staff in hospitals and nursing homes must be able to respond to emergency situations at all times. This requires well-functioning communication and staff location tracking. The ZETTLER® Medical® 800 communication system meets this challenge with the new Nurse Control Station.

The Nurse Control Station represents a logical extension of conventional answer stations and is intended for universal usage as a group, station and parallel control station in duty rooms and other staff rooms. The personnel can answer incoming calls discreetly using the handset or in handsfree mode, exchange all necessary information and initiate appropriate actions.

Convenient call processing

A carefully designed illuminated display indicates all calls and alarms, as well as the set presences of the care personnel. All calls are signalled audibly and visually, and are processed according to defined priorities or the user's own choice. The volume of calls forwarded to the patients' rooms and of the audibly signal at the control station can be controlled, e.g. for adaptation to day/night shifts.

ZETTLER® Medical® 800 Nurse Control Station

Flexible key assignment

Eight keys with LED status indicators are available for project-specific special functions. This has the advantage that frequently used functions, which would otherwise require several operating steps, can be assigned to shortcut buttons. Standard operations, e.g. emergency call triggering and activation of a door opener, have default key assignments. New assignments can be easily programmed by nursing personnel.

Direct contacting and announcements

Care personnel work is reduced by the possibility of directly addressing patients and colleagues at their indicated location. Patients contacted in this manner may disable the monitoring lock by pressing the call button and answer the nurse who can then automatically continue speaking handsfree. Building, station and group announcements as well as announcements to specific rooms where care personnel is present can be made conveniently and quickly.

Additional control functions

Control functions such as remote control of terminals at doors and access control systems can be integrated in the Medical® system. Separate entry phones become superfluous, and workplace complexity in the duty room is reduced. Moreover, internal fault messages and external messages, e.g. from alarm signaling systems, can be received and acknowledged - a common requirement for hospital safety.

Support in the care organisation

The Nurse Control Station also provides support in the administration of stations and entire buildings. It can manage up to 15 stations and up to 5 groups per station. Adapted to duty rotas, the required group can be quickly selected from among several preconfigured combination variants. The groups and stations of a shift are automatically combined by making the selection, and work as a unit.

Solutions to every need

Different control options are desirable depending on the size and organisation of a hospital or nursing home. Tyco offers other alternatives over and above the Nurse Control Station. The room terminals of the ZETTLER® control units provide all basic functions of a control station: call answering, storage or deletion of calls.

The universal variant of the call terminal - equipped with a display and a handset - has various mounting options and is suitable particularly for duty rooms and checkpoints.

Many nurses are constantly on the move and therefore carry DECT terminals. In conjunction with the PABX, these mobile phones can also double as portable nurse call terminals. PC answer stations for station duty rooms and building switchboards are solutions that provide optimum convenience. Networked tools, such as logging, integrated floor plans, radio paging and DECT organisations, along with other functions support all areas of a hospital or a nursing home. They come with interfaces for building management and security systems.

Stock Items

Item	Description
Nurse Control Station	Nurse Control Station, with audio
Documentation	Operating instructions, for Nurse Control Station Nurse Control Station - Operating instructions, Short user guide

For further information on how ADT can help you, contact your local ADT Fire and Security office or phone free on **0800 010 999** or visit us at www.adt.co.uk

Head Office: ADT Fire and Security plc, Security House, The Summit, Hanworth Road, Sunbury-on-Thames, Middlesex TW16 5DB.

ADT reserves the right to modify or withdraw any product or service without notice

tyco / Fire & Security

CE

